

Regular care prevents ceramic sanitary ware from lime scale and rust deposits build up. Sanitary ware should be cleaned with a soft brush using mild detergent. You should only use detergents recommended for ceramic sanitary ware products. Carefully read the instruction on the detergent pack.

You should not use abrasive tools and cleaners such as wire mesh and abrasive sponges. It is forbidden to use concentrated acids and strong alkaline agents as they can damage the glazed surface.

To remove rust stains and spots use special cleaners (liquids, pastes and powders) which contain certain rust dissolving acids. Water-soluble salts – the result of chemical reaction with such cleaners – can easily be washed off with water. In order to keep healthy environment in your bathroom we recommend using disinfectants for cleaning your sanitary ware.

If your WC is kept in a non-heated room during winter, its bowl and tank should be drained and dried in order to prevent destruction of sanitary ware and fittings. Do not use ceramic sanitary ware if the environmental temperature is below 1C °.

When using ceramic sanitary ware you should not:

- throw trash and household waste into the toilet;
- dump cement and adhesive mixtures into the toilet;
- stand on the toilet seat or cover.

You should also properly use and take care of the toilet seat with lid. To prevent deformation, color changing and scratching do not use rough abrasive cleaners and corrosive agents (acids and paintwork materials). Do not put heavy and solid objects onto the toilet seat and lid.